



Hideaway Plus

Undercounter and inwall	
front cistern access	07
Inwall rear cistern access	10
Cistern Access	12
Cistern Techs	14
How to create your	
Hideaway Plus suite	16



Pairing

Hideaway Plus gives you the freedom to create your perfect look by combining different buttons and pans.





Hideaway Plus

Undercounter and inwall front cistern access



1. Sensor Button
Black Glass, Blue Lights
Infrared Hand User Detection
9509614



2 Metal Button Chrome 1804856



3 Metal Button Brushed Nickel 1804858



Metal Button Brushed Gold 1804859



5 Metal Button Matte Black 1804857



6 Thin Button Chrome 9508204



7 Thin Button Brushed 9508207



8 Thin Button Brushed Nickel 9508205



9 Thin Button Champagne 9508226



10 Thin Button Full Matte Black 9508206

1

Black glass sensor button Invisible fixing points 238 x 154 mm 2 —5

Metal Button Invisible fixing points 240 x 156 mm 6 — 10

ABS plastic buttons and plate Invisible fixing points 232 x 148mm



11 Rectangle Button Chrome 9503683



12 Rectangle Button Silver 9503684



13 Rectangle Button White 9503682



14 Rectangle Button Black 9503685



15 Rectangle Button Brushed 9508203



16 Rectangle Button Brushed Nickel 9508201



17 Rectangle Button Champagne 9508202



8 Rectangle Button Full Matte Black 9508200

11 — 14

ABS plastic buttons and plate Invisible fixing points Chrome button trim 232 x 148

15 — 18

ABS chrome plastic buttons Stainless steel backing plate Invisible fixing points 232 x 148mm







20 Round Button Brushed Stainless Steel 9504474



21 Round Button White Glass 9504472



22 Round Button Black Glass 9504471

ABS chrome plastic buttons Stainless steel backing plate Invisible fixing points 232 x 148mm

21 — **22**

ABS chrome plastic buttons Glass backing plate Invisible fixing points 232 x 148mm

Hideaway Plus

Inwall rear cistern access



23 Round Button
Brushed Stainless Steel
9503691



24 Round Button Polished Stainless Steel 9503690



25 Round Button White Glass 9503688



26 Round Button Black Glass 9503687





27 Round Button Chrome 9503686

Rear Cistern Access ABS chrome plastic buttons Stainless steel backing plate Invisible fixing points 175 x 108mm

25 - 26

Rear Cistern Access
ABS chrome plastic buttons
Glass backing plate
Invisible fixing points
175 x 108mm

27


Rear Cistern Access ABS chrome plastic buttons 46mm

Cistern Access

Choose the right option for your bathroom design.


There are three types of cistern access when installing a Hideaway Plus suite.

Be sure to understand your access alternatives before selecting your buttons.



01 Front Cistern Access

Cistern access is gained directly above the pan behind the button. Button is placed on front of wall.



02 Rear Cistern Access

Cistern access is gained from rear of wall. Cistern must be mounted directly above the pan. 4 metres of hose supplied so buttons can be placed away from the pan providing you with flexible mounting solutions.

03 Under Counter Access

Cistern access is gained directly behind the button. Button can be placed on front or top of half wall, or counter.

Cistern Techs

Inwall Cisterns

Suits Front & Rear Access

Cistern Features:


Anti-condensation foam for moisture prevention behind the wall


Powder coated enamelled galvanised steel frame for more support and durability (wall hung only)


7 year warranty

WELS 4 star, 4.5/3 L/per flush with the ability to adjust to 6/3 L/per flush

Easy to install and service for installation flexibility







Wall Hung 9503670

Back to Wall 9503671

Undercounter Cisterns

Suits Front and Top Access

Cistern Features:


Anti-condensation foam for moisture prevention behind the wall


Powder coated enamelled galvanised steel frame for more support and durability (wall hung only)


7 year warranty


WELS 4 star, 4.5/3 L/per flush with the ability to adjust to 6/3 L/per flush


Easy to install and service for installation flexibility











Wall Hung 9508061

Back to Wall 9508062


3 steps to create >

How to create your


Hideaway Plus suite

Step 1 Know your access

Step 2 Select your button



Inwall Rear access



Step 3 Choose a pan

1 2	Sensor Button Black Glass 9509614 Metal Button Chrome 1804856	Back to Wall Pan	Wall Hung Pan
	Metal Button Criome 1804858		
3	Metal Button Brushed Gold 1804859		
4	Metal Button Matte Black 1804857		M
5	Thin Button Chrome 9508204		
6	Thin Button Brushed 9508207		
7	Thin Button Brushed Nickel 9508205	Hideaway Plus Inwall Cistern Back to Wall 9503671	Hideaway Plus Inwall Cistern Wall Hung 9503670
8		Back to Wall 9505671	Wall Hung 9505670
9	Thin Button Champagne 9508226 Thin Button Full Matte Black 9508206		
10		Back to Wall Pan PRODUCT CODE	Wall Hung Pan PRODUCT CODE
11	Rectangle Button Chrome 9503683	PRODUCT CODE	PRODUCT CODE
12	Rectangle Button Silver 9503684		
13	Rectangle Button White 9503682		
14	Rectangle Button Black 9503685		
15	Rectangle Button Brushed 9508203		
16	Rectangle Button Brushed Nickel 9508201	Hideaway Plus Undercounter Cistern Back to Wall 9508062	Hideaway Plus Undercounter
17	Rectangle Button Champagne 9508202	Cistern Back to Wall 9508062	Cistern Wall Hung 9508061
18	Rectangle Button Full Matte Black 9508200		
19	Round Button Polished Stainless Steel 9504473		
20	Round Button Brushed Stainless Steel 9504474		
21	Round Button White Glass 9504472		
22	Round Button Black Glass 9504471		
18	Round Button Brushed Stainless Steel 9503691	Back to Wall Pan	Wall Hung Pan
19	Round Button Polished Stainless Steel 9503690	PRODUCT CODE	PRODUCT CODE
20	Round Button White Glass 9503688		
21	Round Button Black Glass 9503687		
22	Round Button Chrome 9503686		

Hideaway Plus Inwall Cistern Back to Wall 9503671 Hideaway Plus Inwall Cistern Wall Hung 9503670



Bathroom Happiness

Visit any one of our 300 showrooms around Australia for all the latest products, concepts and inspiration to make your bathroom whatever you want it to be. And for the ultimate bathroom experience, go to one of our bathroom life" stores where you will find the biggest range of leading Australian and international brands.

Call 1800 032 566 or visit www.reece.com.au for your nearest bathroom showroom.

Due to limitations in the printing process the colours in this brochure are a guide only. The manufacturer/distributor reserves the right to vary specifications or delete models from their range without prior notification. The manufacturer/distributor takes no responsibility for printing errors. Hideaway Plus invall cisterns and buttons enjoy a 10 year product replacement warranty and a one year parts and labour warranty - Domestic use only. See www.reece.com.au/warranties for more information.



