



Hideaway Plus

Undercounter and inwall	
front cistern access	07
Inwall rear cistern access	10
Cistern Access	12
Cistern Techs	14
How to create your	
Hideaway Plus suite	16



Pairing


Hideaway Plus gives you the freedom to create your perfect look by combining different buttons and pans.





Hideaway Plus

Undercounter and inwall front cistern access




1. Sensor Button
Black Glass, Blue Lights
Infrared Hand User Detection
9509614



2 Thin Button Chrome 9508204



3 Thin Button Brushed 9508207



4 Thin Button Brushed Nickel 9508205



5 Thin Button Champagne 9508226



6 Thin Button Full Matte Black 9508206

Black glass sensor button

2 — 6


ABS plastic buttons and plate Invisible fixing points 232 x 148



7 Rectangle Button Chrome 9503683



8 Rectangle Button Silver 9503684



Rectangle Button White 9503682



10 Rectangle Button Black 9503685



11 Rectangle Button Brushed 9508203



12 Rectangle Button Brushed Nickel 9508201



13 Rectangle Button Champagne 9508202



14 Rectangle Button Full Matte Black 9508200

7 — 10

ABS plastic buttons and plate Invisible fixing points Chrome button trim 232 x 148

11 - 14

ABS chrome plastic buttons Stainless steel backing plate Invisible fixing points 232 x 148mm



15 Round Button Polished Stainless Steel 9504473



16 Round Button Brushed Stainless Steel 9504474



17 Round Button White Glass 9504472



18 Round Button Black Glass 9504471

15 — **16**

ABS chrome plastic buttons Stainless steel backing plate Invisible fixing points 232 x 148mm

17 — 18

ABS chrome plastic buttons Glass backing plate Invisible fixing points 232 x 148mm

Hideaway Plus

Inwall rear cistern access



19 Round Button Brushed Stainless Steel 9503691



20 Round Button Polished Stainless Steel 9503690



21 Round Button White Glass 9503688



22 Round Button Black Glass 9503687





23 Round Button Chrome 9503686

19 - 20

Rear Cistern Access ABS chrome plastic buttons Stainless steel backing plate Invisible fixing points 175 x 108mm

21 - 22

Rear Cistern Access ABS chrome plastic buttons Glass backing plate Invisible fixing points 175 x 108mm

23


Rear Cistern Access ABS chrome plastic buttons 46mm

Cistern Access

Choose the right option for your bathroom design.


There are three types of cistern access when installing a Hideaway Plus suite.

Be sure to understand your access alternatives before selecting your buttons.



01 Front Cistern Access

Cistern access is gained directly above the pan behind the button. Button is placed on front of wall.



02 Rear Cistern Access

Cistern access is gained from rear of wall. Cistern must be mounted directly above the pan. 4 metres of hose supplied so buttons can be placed away from the pan providing you with flexible mounting solutions.

03 Under Counter Access

Cistern access is gained directly behind the button. Button can be placed on front or top of half wall, or counter.

Cistern Techs

Inwall Cisterns

Suits Front & Rear Access

Cistern Features:


Anti-condensation foam for moisture prevention behind the wall


Powder coated enamelled galvanised steel frame for more support and durability (wall hung only)


7 year warranty

WELS 4 star, 4.5/3 L/per flush with the ability to adjust to 6/3 L/per flush

Easy to install and service for installation flexibility







Wall Hung 9503670

Back to Wall 9503671

Undercounter Cisterns

Suits Front and Top Access

Cistern Features:

Anti-condensation foam for moisture prevention behind the wall


Powder coated enamelled galvanised steel frame for more support and durability (wall hung only)


7 year warranty


WELS 4 star, 4.5/3 L/per flush with the ability to adjust to 6/3 L/per flush


Easy to install and service for installation flexibility











Wall Hung 9508061

Back to Wall

3 steps to create >

How to create your

Hideaway Plus suite

Step 2 Select your button Step 1 Know your access **Inwall Front** access 00 Select **Undercounter** access 13 Select **Inwall Rear** access Select 00

Step 3 Choose a pan

1. 2	Sensor Button Black Glass 9509614 Thin Button Chrome 9508204	Back to Wall Pan PRODUCT CODE	Wall Hung Pan PRODUCT CODE	
3	Thin Button Brushed 9508207			
4	Thin Button Brushed Nickel 9508205			
5	Thin Button Champagne 9508226		/11	
6	Thin Button Full Matte Black 9508206			
7	Rectangle Button Chrome 9503683	Hideaway Plus Inwall Cistern	Hideaway Plus Inwall Cistern	
8	Rectangle Button Silver 9503684	Back to Wall 9503671	Wall Hung 9503670	
9	Rectangle Button White 9503682			
10	Rectangle Button Black 9503685	Back to Wall Pan	Wall Hung Pan	
11	Rectangle Button Brushed 9508203	PRODUCT CODE	PRODUCT CODE	
12	Rectangle Button Brushed Nickel 9508201			
13	Rectangle Button Champagne 9508202			
14	Rectangle Button Full Matte Black 9508200		/1]	
15	Round Button Polished Stainless Steel 9504473			
16	Round Button Brushed Stainless Steel 9504474	Hideaway Plus Undercounter	Hideaway Plus Undercounter	
17	Round Button White Glass 9504472	Cistern Back to Wall 9508062	Cistern Wall Hung 9508061	
18	Round Button Black Glass 9504471			
18	Round Button Brushed Stainless Steel 9503691	Back to Wall Pan	Wall Hung Pan	
19	Round Button Polished Stainless Steel 9503690	PRODUCT CODE	PRODUCT CODE	
20	Round Button White Glass 9503688			
21	Round Button Black Glass 9503687			
22	Round Button Chrome 9503686			
		Hideaway Plus Inwall Cistern Back to Wall 9503671	Hideaway Plus Inwall Cistern Wall Hung 9503670	



Bathroom Happiness

Visit any one of our 300 showrooms around Australia for all the latest products, concepts and inspiration to make your bathroom whatever you want it to be. And for the ultimate bathroom experience, go to one of our bathroom life" stores where you will find the biggest range of leading Australian and international brands.

Call 1800 032 566 or visit www.reece.com.au for your nearest bathroom showroom.

Due to limitations in the printing process the colours in this brochure are a guide only. The manufacturer/distributor reserves the right to vary specifications or delete models from their range without prior notification. The manufacturer/distributor takes no responsibility for printing errors. Hideaway Plus inwall cisterns and buttons enjoy a 10 year product replacement warranty and a one year parts and labour warranty. Openestic use only. See www.reece.com.au/warranties for more information.



